Setup of outgoing calls using Saving automat (LCR)

This procedure is related to extensions in the basic part of OmegaLite, not to VoIP extensions!

- 1) Write down the routing plan (prefixes)
- 2) Enable the Saving automat (LCR) for certain extensions
- 3) Create Tracks
- 4) Set up the routing table (Dial analysis)

Write down the routing plan (prefixes)

First, make a routing plan for all types of outgoing calls you are going to make. It must take care of the numbering plan you have in Omega (basic part and VoIP). Clear plan could save you a lot of time!

Enable the Saving automat (LCR) for certain extensions

- Go to Internal lines --- Access to external ---- Authorization.
- Check checkboxes "Use" of those extensions that should have right to use Saving automat.

Create Tracks

- Go to External lines ---- Trunks
- o Check existing trunks settings or create new trunks, if needed.
- Go to Saving automat ---- Providers (optionally, if you need to add some prefix)
- Set up provider (prefix to be added)
- Go to Saving automat ---- Tracks
- o Select Trunk
- Set up Days/Time
- Set up remove/add (optionally)

Set up the routing table (Dial analysis)

- Go to Saving automat ---- Dial analysis
- Create a raw
- Set up a mask (optionally)
- o Set the prefix (number)
- Select the Track
- Check the interpretation!!!