

Setup of incoming calls from PSTN/GSM to the reception desk extension

This procedure is related to extensions in the basic part of OmegaLite, not to VoIP extensions!

- 1) Define the reception desk extension number
- 2) Set up a ringing table for the PSTN/GSM line

Define the reception desk extension number

First, specify which will be number of the reception desk extension e.g. number 11.

Set up a ringing table for the PSTN/GSM line

- Go to External lines --- Ringing
- Select the tab (bottom of the page) of the appropriate PSTN/GSM lines (Note: Analogue lines are labeled "External").
- In the Tab selection table select **New** to create a ringing table for the selected external line.

Ring IL 11

Wait Forever

Hang up